SIEMENS



Actuators for air dampers and control valves of oil burners SQM1... SQM2...

Reversible electromotoric actuators

٠	Torques:	- SQM1	up to 10 Nm		
		- SQM2	up to 20 Nm		
•	Running times:	- SQM1	14100 s		
	-	- SQM2	2966 s		
•	Versions:	- Clockwise	e or counterclockwise rotation		

The SQM... and this Data Sheet are intended for use by OEMs which integrate the actuators in their products!

Use

The reversible actuators of the SQM... range are for use in connection with controllers or switching devices equipped with changeover contacts.



To avoid injury to persons, damage to property or the environment, the following warning notes must be observed!

Only qualified staff may open, interfere with or modify the actuators!

- All activities (mounting, installation and service work, etc.) must be performed by qualified staff
- Before making any wiring changes in the connection area, completely isolate the plant from mains supply (all-polar disconnection). Ensure that the plant cannot be inadvertently switched on again and that it is indeed dead. If not observed, there is a risk of electric shock hazard
- Ensure protection against electric shock hazard by providing adequate protection for the connection terminals and by securing the housing cover
- Each time work has been carried out (mounting, installation, service work, etc.), check to ensure that wiring is in an orderly state
- Fall or shock can adversely affect the safety functions. Such units must not be put into operation, even if they do not exhibit any damage

Mounting notes

- Ensure that the relevant national safety regulations are complied with
- When mounting actuator and damper linkage, the gear train can be disengaged with a lever, thus allowing the actuator's drive shaft to be easily adjusted in either direction of rotation

Applied directives: CE

Low-voltage directive

2014/35/EC 2014/30/EC

Compliance with the regulations of the applied directives is verified by the adherence to the following standards / regulations:

Electromagnetic compatibility EMC (immunity)

- Automatic electrical controls for household and similar use DIN EN 60730-1 • Part 1: General requirements
- Automatic electrical controls for household and similar use DIN EN 60730-2-14 • Part 2-14: Particular requirements for electric actuators

The relevant valid edition of the standards can be found in the declaration of conformity!



EAC Conformity mark (Eurasian Conformity mark)



ISO 9001:2008 ISO 14001:2004 OHSAS 18001:2007

In combination with the burner control

Туре		
SQM10.15502	•	•
SQM10.15561	•	•
SQM10.15562	•	•
SQM10.16102	•	•
SQM10.16501	•	•
SQM10.16502	•	•
SQM10.16532	•	•
SQM10.16561	•	•
SQM10.16562	•	•
SQM10.17502	•	•
SQM11.15502		•
SQM11.15562		•
SQM11.16501		•
SQM11.16502		•
SQM20.16502		•
SQM20.18501		•
SQM20.18502		•
SQM21.16502		•
SQM21.18501		•
SQM21.18502		•

Disposal notes



The actuator contains electrical and electronic components and must not be disposed of together with household waste.

Local and currently valid legislation must be observed.

Mechanical design	
Housing	 The actuator's cover is made of impact-proof and heat-resistant plastic. Color of cover: Dark-grey The housing of the gear train in made of die-cast aluminum and has 4 threaded holes for cable glands Pg11
Actuator	- Reversible, locking-proof synchronous motor
Adjustment of switching points	 With adjustable cams Setting scales beside the cams give the switching point's angular position Cams can be adjusted manually, either with the enclosed hook spanner or tool
Position indicator	- Internally: Scale at the beginning of the cam stack on the gear train side
	 Only SQM21: Equipped with position indicator visible from outside (also refer to «Dimensions»)
Electrical connections	- Screw terminals
Gear train	 The reduction gearing has self-lubricating sinter-bronze bearings and requires no maintenance
Drive shaft	- Ready fitted to the front of the gear train
Mounting and fixing	 Gear train front is used as the mounting surface Fixing by means of 3 threaded holes with inside thread M5

Type summary

				•	•		•	•	
Runnin	g time	3)	Direction of rotation	Number of	Nominal	Start-	Hold-	AC 220240 V	AC 110 V
50 Hz 1) for		when facing the	auxiliary	torque ²)	ing	ing	4)	4)
angular	rotation		drive shaft and with	switches		torque	torque		
			control voltage						
			applied to						
			terminal 1						
90°	130°							Type reference	Type reference
Standa	rd versio	n , di	ameter of drive shaft	10 mm					
14 s	20 s	1	Counterclockwise	5	10 Nm	10 Nm	4 Nm	SQM10.15502	
14 s	20 s	2	Counterclockwise	5	10 Nm	10 Nm	4 Nm	SQM10.15562	SQM10.15561
29 s	42 s	1	Counterclockwise	1	10 Nm	15 Nm	7 Nm	SQM10.16102	
29 s	42 s	1	Counterclockwise	5	10 Nm	15 Nm	7 Nm	SQM10.16502	SQM10.16501
29 s	42 s	1	Counterclockwise	5	10 Nm	15 Nm	7 Nm	SQM10.16532 5)	
29 s	42 s	2	Counterclockwise	5	10 Nm	15 Nm	7 Nm	SQM10.16562	SQM10.16561
70 s	100 s	1	Counterclockwise	5	10 Nm	15 Nm	15 Nm	SQM10.17502	
14 s	20 s	1	Clockwise	5	10 Nm	10 Nm	4 Nm	SQM11.15502	
14 s	20 s	2	Clockwise	5	10 Nm	10 Nm	4 Nm	SQM11.15562	
29 s	42 s	1	Clockwise	5	10 Nm	15 Nm	7 Nm	SQM11.16502	SQM11.16501
Heavy	duty vers	sion							
Diamet	er of drive	sha	ft 12 mm						
Gear tra	ain shafts	mad	e of hardened steel, g	earwheels nit	rated				
Type SQM21 with external position indication (refer to «Dimensions»)									
29 s	42 s	1	Counterclockwise	5	20 Nm	20 Nm	12 Nm	SQM20.16502	
45 s	66 s	1	Counterclockwise	5	20 Nm	20 Nm	12 Nm	SQM20.18502	SQM20.18501
29 s	42 s	1	Clockwise	5	20 Nm	20 Nm	12 Nm	SQM21.16502	
45 s	66 s	1	Clockwise	5	20 Nm	20 Nm	12 Nm	SQM21.18502	SQM21.18501

¹) At frequency 60 Hz, running times are about 17 % shorter

²) Based on 150,000 position changes

³) Wiring according to diagram no.

⁴) Additional types on request

⁵) With thread for mounting an ASK33.9

Ordering

When ordering, please give type references of actuator and accessories according to «Type summary».

In addition to the actuator, the following item is to be ordered separately; it is also supplied separately:

Technical data

General actuator data

Operation voltage

	AC 220240 V, SO 112 - 15 /07 + 10 /0			
	AC 220 V, 60 Hz –15 % / +10 %			
	On request:			
	AC 110 V, 50 / 60 Hz ±6 %			
Switching capacity of end	10 (3) A, AC 24250 V			
and auxiliary switches				
Positioning angle	up to 160° (scale range)			
Mounting position	optional			
Safety class	I			
Degree of protection	IP 54, DIN 40050 (at provided design of			
	cable entry or fastening element for not			
	used holes)			
Cable entry M16 and M20	for			
	2 x M16 x 1.5 and			
	2 x M20 x 1.5			
Weight	approx. 1.7 kg			
Actuator motor	synchronous motor			
Power consumption	9 VA			
Lifecycle	Cycles (CLOSE ⇔ OPEN ⇔ CLOSE)			
	with rated torque: typically 250.000			
Storage	DIN EN 60 721-3-1			
Climatic conditions	class 1K3			
Mechanical conditions	class 1M2			
Temperature range	-20+70 °C			
Humidity	< 95 % r.F.			
Transport	DIN EN 60 721-3-2			
Climatic conditions	class 2K2			
Mechanical conditions	class 2M2			
Temperature range	-50+60 °C			
Humidity	< 95 % r.h.			
Operation	DIN EN 60 721-3-3			
Climatic conditions	class 3K5			
Climatic conditions Mechanical conditions	class 3M2			
Climatic conditions				

AC 220...240 V, 50 Hz -15 % / +10 %



Caution!

Condensation, formation of ice and ingress of water are not permitted!

Function

Environmental conditions

The synchronous motor drives the shaft via the gear train. Attached to the drive shaft is a cam stack which actuates the end and auxiliary switches. The switching position of each end and auxiliary switch can be adjusted within the operating range with the help of the relevant cams.

The control section includes 2 end switches and a maximum of 5 auxiliary switches. In addition, a potentiometer can be integrated (as a feedback potentiometer for P-control, or as a setting unit for slave control, or for remote position indication).

Connection diagram

SQM...

Diagram no. 1 (H 4 318 1521 0)







7812a02/1097

Dimensions



* For remove the cover required distance to walls, devices of burners etc

Dimension table	Ту

Type reference	а	b	С	d	е
SQM1	10h8	3 ^{N9}	4	20	6
SQM2	12h8	3 ^{N9}	4	21.5	4.5

The groove on the drive shaft is in the marked position, when the cam stack of control unit is in the 0° position (as supplied).